APMONG Manual.qxp_Layout 1 28/01/2016 11:44 Page 1

aperta

APMONWG | APMONBG - COLOUR VIDEO DOOR ENTRY MONITOR



USER MANUAL

esp®

www.espuk.com

APMONG Manual.qxp_Layout 1 28/01/2016 11:44 Page 2

APMONG Manual.qxp_Layout 1 28/01/2016 11:44 Page 3

Contents

Monitor Functions Overview 4
Installation 5
Master / Slave Setup 6
Setting Address ID - Only required for apartment systems 7
Setting the Time and Date 8
Monitor Image and Talk Volume Adjustment 9
Changing Monitor Ringtone 10
Monitor Ringtone Volume Adjustment 11
Preview Door Station's Camera Image 12
Inner Call - Calling to another monitor on the system or within the apartment 13
Intercom Call - Calling to another monitor for multiple occupancy system 14
SD Card Record and Viewing Options 15
Monitor Installation Setup - Setting the monitor as a Guard Unit 16
Guard Unit Facility - Calling to a monitor set to 'Guard Unit' mode 17
Restore Monitor Settings to Default 18

System Cabling


All system cabling (excluding mains 240vAC supply) has been tested with Cat5E UTP PVC cable.

ELAND CABLES

Part Number - A8NFORCE5EUTP

Find this product online:
elandcables.com | Cables & Accessories | LAN Cable | Cat 5E UTP PVC Cable

Monitor Functions Overview




A	B	C	D	Then choose between these 2 options	
The visitor presses the call button on the door station	A chime will sound from the monitor	The visitor's image will appear on screen	Press the 'Talk' button and begin conversation	Press the 'Talk' button to end call	Press the 'Lock' button and select Lock1 or Lock2 to release

Installation



Site the indoor monitor to suit application.




1-Gang Mount Box
(if required, not supplied)

Surface mount the bracket of the monitor or if required onto a 1-gang mount box (not supplied).

Make the system connections to the back of the monitor as per below and then slide the monitor onto the bracket using the hooks to hold firmly in place.

Rear View of Monitor




Master / Slave Setup


Switch Setup

For villa system:
Only 1 monitor is set as a MASTER.
All other monitors are set to SLAVE.

For apartment system:
Each Address ID has 1 MASTER.
All other monitors on the same
Address ID are set to SLAVE.



Menu Setup



Setting Address ID - Only required for apartment systems

A



In standby mode

Press the
'Menu' button



The time will appear

Press and hold the
Key for 5 seconds



The Installation Setup
screen will display

B

Press the 'Down' button
to select 'Local Address'



Press the 'Right' button
to change Address ID number



The address number will change
as the 'Right' button is pressed.
Select an Address ID from 01-32

C

Press the 'Menu' button when
the required number appears

Press 'Exit'
two times



The time will appear, after 10
seconds the monitor will return to standby
mode, the setup will be complete

Setting the Time and Date

A



In standby mode

Press the ‘Menu’ button



The time will appear

Press the ‘Menu’ button



The Main Menu screen will display

B



Press the ‘Right’ button until User Setup is highlighted

Press the ‘Menu’ button



The User Setup screen will display

Press the ‘Menu’ button



The Date & Clock screen will display

C



Use the ‘Right’ button to select value

Use the ‘Up or Down’ button to change value

Press the ‘Menu’ button to save changes

Press ‘Exit’ two times



The time will appear, after 10 seconds the monitor will return to standby mode, the setup will be complete

Monitor Image and Talk Volume Adjustment

A



In standby mode

Press the
'Preview' button




The image from the door
station will appear

Press the
'Menu' button



The adjustment menu will appear
down the right handside of the screen

B




Press 'Down' button
to select option

Press 'Right or Left ' button
to adjust the option



Once adjusted,
Press 'Down' to 'Return'



Press the 'Menu' button then 'Exit'
to complete setup

Changing Monitor Ringtone

A



In standby mode

Press the ‘Menu’ button



The time will appear

Press the ‘Menu’ button



The Main Menu screen will display

B



Press the ‘Right’ button until Ring Setup is highlighted

Press the ‘Menu’ button




The Ring Setup screen will display

Press the ‘Menu’ button to access the ‘Door Station Call Tone’ menu

C

Use the ‘Up or Down’ button to select the Address ID of the outdoor station required and press ‘Menu’



Press ‘Left or Right’ button To change the ringtone option and press ‘Menu’



The Ring Setup menu also gives tone options for inner calls and door bell facility

Monitor Ringtone Volume Adjustment

A



In standby mode

Press the
'Menu' button



The time will appear

Press the
'Menu' button



The Main Menu screen
will display

B



Press the 'Right' button
until User Setup is highlighted

Press the
'Menu' button




The following User Setup
screen will display

Press 'Down' to select
'Ring Mode' and press 'Menu'



The Ring Mode screen
will display

C



Use the 'Right' button
to select value

Use the 'Up or Down'
button to change value

Press the 'Menu' button
to save changes

Preview Door Station's Camera Image

A



In standby mode

Press the 'Menu' button



The time will appear

Press the 'Menu' button



The Main Menu screen will display

B



Press the 'Right' button until Monitor is highlighted

Press the 'Menu' button



The following Monitor Select screen will display

Use the 'Up or Down' button to select camera then 'Menu' to view

Inner Call - Calling to another monitor on the system or within the apartment

A



In standby mode

Press the ‘Menu’ button



The time will appear

Press the ‘Menu’ button



The Main Menu screen will display

B



Press the ‘Right’ button until Intercom is highlighted

Press the ‘Menu’ button



The Intercom screen will display

Press ‘Down’ then‘Menu’ button to activate an Inner Call

C



All system monitors will ring

Once one Monitor has ‘Talk’ button pressed the inner call can begin

Intercom Call - Calling to another monitor for multiple occupancy system

A



In standby mode

Press the ‘Menu’ button



The time will appear

Press the ‘Menu’ button



The Main Menu screen will display

B



Press the ‘Right’ button until Intercom is highlighted

Press the ‘Menu’ button



The Intercom screen will display

Press the ‘Menu’ button to access the Intercom menu

C

Use the ‘Up or Down’ button to select the Address ID of Monitor required



Press the ‘Menu’ button once Address ID is selected

Once the call receiver has pressed ‘Talk’ the call can begin

SD Card Record and Viewing Options

A



In standby mode

Press the
'Menu' button




The time will appear

Press the
'Menu' button




The Main Menu screen
will display

B



Press the 'Right'
button until SD Card
Memory is highlighted

Press the 'Menu' button
and the SD Card Memory
screen will display



Press the 'Menu' button on this option to select between 'Photo- taking' and 'Video-Taking'mode

Scroll down and select this option to view and delete the internal memory storage of photos

Press the 'Menu' button on this option to view photos stored on the SD card

Scroll down and select this option to view the video filesstored on the SD card

Press the 'Menu' button on this option to delete all files on the SD card

Monitor Installation Setup - Setting the monitor as a Guard Unit

A




In standby mode



Press the
'Menu' button



The time will appear



Press and hold the
Key for 5 seconds




The Installation Setup
screen will display

B



Press the 'Down' button
to select 'Guard Unit'





Press the 'Right' button
to change Guard Unit On [8004]



The address number
will change as the
'Right' button is pressed

C



Press the 'Menu' button



Press 'Exit'



The time will appear, after 10
seconds the monitor will return to standby
mode, the setup will be complete

Guard Unit Facility - Calling to a monitor set to 'Guard Unit' mode

A



In standby mode

Press the 'Menu' button



The time will appear

Press the 'Menu' button



The Main Menu screen will display

B



Press the 'Right' button until Intercom is highlighted

Press the 'Menu' button



The Intercom screen will display

Press 'Down' then 'Menu' button to activate 'Direct Call Guard Unit'

C



Only monitors set to 'Guard Unit' Mode will ring

Once the Guard Unit has 'Talk' button pressed the call can begin

Restore Monitor Settings to Default

A



In standby mode

Press the ‘Menu’ button



The time will appear

Press the ‘Menu’ button



The Main Menu screen will display

B



Press the ‘Right’ button until User Setup is highlighted

Press the ‘Menu’ button



The following User Setup screen will display

Press ‘Down’ to select ‘Restore to Default’

C

Press the ‘Menu’ button to confirm

APMONG Manual.qxp_Layout 1 28/01/2016 11:44 Page 19

APMONG Manual.qxp_Layout 1 28/01/2016 11:44 Page 20

Elite Security Products
Unit 7, Target Park, Shawbank Rd
Lakeside, Redditch B98 8YN



Telephone: 01527 51 51 50
Fax: 01527 51 51 43
email: info@espuk.com

E&OE - Errors and omissions excepted. A16