

THP1-C Simplified Instructions

The feature of the LCD display and keys:
THPW1-C LCD display




Fig 1




Fig 2

Description of each key function:

- P** - To enter into program mode
- ⬆** - To view **☀** an **🌙** Temperatures
- 🕒** - To enter into time and day adjustment mode
- Reset** - To reset the unit into initial mode
- Ⓜ** - To turn on and off of the unit
- 🏠** - To enter into Vacation mode
- ➡** - To confirm setting
- ☀** - To override into CT (COMFORT Temperature) mode (20°C)
- 🌙** - To override into ET (ECONOMY Temperature) mode (17°C)
- +** - Temporary temperature override mode or increase value adjustment
- - Temporary temperature override mode or decrease value adjustment

Setting current Day and Time -

Press Clock Button.

Press + or – button to adjust hour. Press OK/Enter button to confirm

Press + or – button to adjust minutes. Press Ok/Enter button to confirm.

The Day is flashing. Press + or – button to adjust Day. Press Ok/Enter button to confirm.

To View programs –

Press program button.

You can scroll through each hour of the day by pressing + or – button.

You will see that each hour is set to either CT or ET

If you press ok/enter button it will scroll to the next day.

There is a pre set program already set – see table below

Heating & Air-Conditioning Program



Day	CT period	ET period	Display Program Schedule
MO-FR	6:00-7:59 & 16:00-22:59	23:00-5:59 & 8:00-15:59	
SA-SU	7:00-22:59	23:00-6:59	

Fig 3.1

To change a preset program –

Press Program button to enter program mode.

Press ok/enter button to select day of the week.

Press + or – button to scroll though hours in the day.

Press the CT button or ET button for each hour of the day.

Important Note –

Do not set the beginning and end of the program to 0:00 due to the thermostat needing this time for its reference use.

Therefore you must set the beginning or end time at 23:00 or 1:00.

Changing the CT or ET Temperature

Press the Temp button.
Press CT button or ET button
Press + or – to adjust temp
Press ok/enter button to confirm setting.

Setting Vacation Temperature or Permanent override

Press Vacation button.
Use + or – button to adjust amount of days vacation (0– 99 days)
If you choose to leave as ‘- - ‘this will be a permanent override.
Press ok/enter button to confirm.

To cancel vacation / permanent override – Press CT or ET button or even power button to turn unit off.

Setting Temporary manual override temperature

This function allows you to change the present temperature for a set period of between 1 to 48 hours.

Press + or – button to set required temperature.
Press ok/enter button to confirm.
Press + or – to set number of hours.
Press ok/enter button to confirm.
(Press CT or ET button to exit)

Setting Temporary override program temperature –

Function allows you to temporarily override the CT temp from the ET temp settings, until next CT setting (or vice versa).

If unit is running at CT program period.
Press ET Button to change CT to ET setting (until next CT program period)
Press + or – to set temperature
Press ok/enter to confirm
Set number of hours override

If unit is running at ET program period.
Press CT Button to change ET to CT setting (until next ET program period).
Press + or – to set temperature
Press ok/enter to confirm
Set number of hours override

IMPORTANT

This unit should be installed to current IEE wiring regulations if in doubt consult a qualified electrician.